



BRUSH GUARD
WILL FIT YAMAHA® DRIVE®
INSTALLATION INSTRUCTIONS
14-011 (BLACK) 14-012 (STAINLESS)

INCLUDED:

- MADJAX® BRUSH GUARD
- 2 UPPER MOUNTING BRACKETS
- LOWER MOUNTING BRACKET
- MOUNTING HARDWARE



Brush Guard



Upper Mounting Brackets



Lower Mounting Bracket



**ATTACH
HARDWARE**

1

Attach upper and lower mounting brackets to brush guard using hardware provided.

Remove factory bolts from both front struts. Attach Brush Guard using factory bolts.

2



REMOVE HARDWARE



Remove bolt from cowling mounting tab. Attach Brush Guard between cowling and mounting tab. Tighten Hardware.

3

BRUSH GUARD HARDWARE PACK

3 HEX HEAD BOLTS (BRACKET MOUNTING HARDWARE)

Yamaha®, the Tuning Fork logo, and the Drive® are registered trademarks of Yamaha Golf Cart Company (Yamaha). Any reference to Yamaha's trademarks and products is only for purposes of identifying golf carts with which this Madjax product is compatible. Madjax products are aftermarket parts and are not original equipment parts. Madjax is not connected with, endorsed by, or otherwise affiliated with or sponsored by Yamaha Golf Cart Company or any of its parent or subsidiary companies.

VISIT WWW.MYMADJAX.COM FOR INSTALLATION VIDEOS